




- DE** Montageanleitung
- FR** Instructions de montage
- EN** assembly instructions
- IT** Istruzioni per Installazione
- ES** Instrucciones de montaje
- NL** Handleiding
- DK** Monteringsvejledning
- PT** Manual de Instalação
- PL** Instrukcja montażu
- CS** Montážní návod
- SK** Montážny návod
- ZH** 组装说明
- RU** Инструкция по монтажу
- HU** Szerelési útmutató
- FI** Asennusohje
- SV** Monteringsanvisning
- LT** Montavimo instrukcijos
- HR** Uputstva za instalaciju
- TR** Montaj kılavuzu
- RO** Instrucțiuni de montare
- EL** Οδηγία συναρμολόγησης
- SL** Navodila za montažo
- ET** Paigaldusjuhend
- LV** Montāžas instrukcija
- SR** Uputstvo za montažu



- Isiflex** 28278XXX (80 cm)
- Isiflex** 28272XXX (125 cm)
- Isiflex** 28276XXX (160 cm)
- Isiflex** 28275XXX (175 cm)
- Isiflex** 28274XXX (200 cm)



- Comfortflex** 28167XXX (125 cm)
- Comfortflex** 28168XXX (160 cm)
- Comfortflex** 28162XXX (175 cm)
- Comfortflex** 28169XXX (200 cm)





- Sensoflex** 28132XXX (125 cm)
- Sensoflex** 28133XXX (150 cm)
- Sensoflex** 28136XXX (160 cm)
- Sensoflex** 28135XXX (175 cm)
- Sensoflex** 28134XXX (200 cm)





Boiler-Gas.ru

Перейти на сайт



< 50 °C



	L	ACS	DVGW	KIWA	NF	SVGW	WRAS
Isiflex 28278XXX	80 cm					X	X
Isiflex 28272XXX	125 cm		CQ0363	X	X	X	X
Isiflex 28276XXX	160 cm		CQ0363	X	X	X	X
Isiflex 28275XXX	175 cm					X	
Isiflex 28274XXX	200 cm		CQ0363	X	X	X	X
Comfortflex 28167XXX	125 cm	X			X	X	X
Comfortflex 28168XXX	160 cm	X			X	X	
Comfortflex 28162XXX	175 cm	X				X	
Comfortflex 28169XXX	200 cm	X			X	X	
Sensoflex 28132XXX	125 cm		CN0289			X	
Sensoflex 28133XXX	150 cm					X	
Sensoflex 28136XXX	160 cm		CN0289			X	
Sensoflex 28135XXX	175 cm					X	
Sensoflex 28134XXX	200 cm		CN0289			X	



Boiler-Gas.ru

Перейти на сайт